

before first use:

1. remove cellophane protective wrap from filter and follow steps to activate
2. wash bottle with soapy water

*note: your bottle's lid and collar may be tight initially but will loosen after the first few uses
please direct all questions or comments to drink@hydrosbottle.com*


hydros®

changing and activating your fast flow filter™

filling your hydros bottle

opening/closing your bottle


1. holding your bottle



note: collar fill port must be fully closed when turning lid


for ease of use, grip your bottle across the white band when rotating collar or lid

4. soak your filter




soak your filter in cool water for 3 minutes then flush with water to activate

1. open your side fill port



grip the collar and turn clockwise (collar shown in closed position)


1. holding your bottle



note: collar fill port must be fully closed when turning lid


for ease of use, grip your bottle across the white band when rotating lid

2. access your filter




palm lid and rotate counter-clockwise until clicked into farthest (unlock) position and lift

5. replace your filter




press the filter back into place by aligning the filter with the opening and pushing down

2. fill your bottle




use a steady stream of water to fill bottle

2. opening your drink spout




palm lid and rotate counter-clockwise to middle (open) position to drink

3. remove your filter




unscrew cap from bottle and push filter up from bottom to remove

6. replace your lid




replace lid, palm lid then rotate clockwise until clicked into the farthest (closed) position

3. close your side fill port



grip the collar and turn counter-clockwise until clicked closed (collar shown in open position)

3. closing your drink spout



palm lid and rotate clockwise until clicked into farthest (closed) position to seal